



For the version without covering,
 please contact: sales@alorair.com



SPARE PARTS LIST
HEPA Pro 770

29	Overload protection switch	module	1	16	Air outlet dust rack	steel net	1
28	indicator lamp	module	1	15	Air outlet support	ABS	1
27	Timer	module	1	14	lower casing	LLDPE	1
26	Control Panel	sheet iron	1	13	Stainless steel spring buckle	stainless steel	4
25	Rotary knob	plastic	1	12	The differential joint	copper	2
24	Main Control Panel	PCB	1	11	The motor bracket	stainless steel	1
23	GFCI outlet	module	1	10	motor	stainless steel	1
22	capacitor clamp	sheet iron	1	9	Guide solar or lunar halo	ABS	1
21	pressure difference switch	plastic	1	8	Compound filter screen	module	1
20	capacitance	module	1	7	G3 filter	module	1
19	Electric control box	galvanized sheet	1	6	Cover Upper	LLDPE	1
18	protective ring	plastic	2	5	R type clamp	plastic	1
17	The power cord buckle	polyamides	1	4	foot pad	TPV	12
				3	Power cord fastener	polyamides	4
				2	bridle line	polyamides	1
				1	dust cap	plastic	1
				No.	Name	Material	Quantity