

For the version without covering,
please contact:sales@alorair.com

Name	Quantity	Name	Quantity
Electric control box cover	1	Water pump	1
Electric control box	1	Fan	1
Guide ring	1	G4 filter	1
Motor bracket	1	Rubber wheel	2
Two fixed strips	1	power cable	1
Air inlet panel	1	Water pipe	1
Pump bottom plate	1	M4*10 stainless steel screw	14
Float fixing bracket	1	Motherboard	1
Pump top fixing plate	1	Operation panel	1
Axle bracket	1	Upper housing	1
Handle fixing bracket (left)	1	Lower housing	1
Handle fixing bracket (right)	1	M6*70	2
Handle fixed cover (left)	1	Humidity Sensor	2
Handle fixed cover (right)	1	Wind ring deck	4
Compressor bracket	1	Capillary	1
Sensor holder	1	Condenser	1
windshield	1	Evaporator	1
Capacitor clip	1	Dosing valve	1
handle	1	foot pad	4
Wind circle	1		
Air outlet cover	1		
Axle bracket	1		
compressor	1		
Compressor capacitance	1		
Fan capacitor	1		

— Restoration & Moisture & Ventilation —



SPARE PARTS LIST

Storm SLGR 850X