



For the version without covering,  
please contact:  
[sales@alorair.com](mailto:sales@alorair.com)

— Restoration & Moisture & Ventilation —

# ALORAIR



## SPARE PARTS LIST

### Zues 900

Add: North Carolina USA  
E-mail: [sales@alorair.com](mailto:sales@alorair.com)

16	air-out protect bracket	φ 3 steel wire	1
15	handle	component	1
14	foot stool	φ 5 steel wire	1
13	foot pad	rubber	4
12	capacitor	8UF 250V	1
11	main board	LLDPE	1
10	card holder	component	1
9	motor bracket	component	1
8	centrifugal motor	component	1
7	power switch	115V 60Hz 16A	1
6	overcurrent protector	115V 60Hz 12A	1
5	PCB	component	1
4	control panel	ABS	1
3	terrace socket	115V 60Hz 10A	1
2	air inlet protect bracket	φ 3 steel wire	1
1	galvanized fixed nut	M6*20	8
No.	Name	Material	Quantity